



SKLO INSTALLATION INSTRUCTIONS: WRAP PENDANT LIGHT

GLOVES (NITRILE) ARE PROVIDED AND **MUST** BE WORN DURING INSTALLATION TO AVOID FINGERPRINTS ON THE FINISH OF THE EXPOSED METAL PARTS.

Congratulations on your purchase of a SkLO wrap pendant light. This product must be installed in accordance with the applicable codes by a person familiar with the construction and operation of the product and the hazards involved, preferably a licensed electrician.

Use maximum 60W bulb.

Step 1

Your SkLO wrap pendant light will arrive assembled, with the hand blown glass wrap element already attached to the light, as shown in the drawing (right). Take great care during unpacking and installation not to damage the delicate glass wrap.

Step 2

Carefully supporting the glass and fixture, connect the exposed leads on the fixture to the leads in the electrical box according to the wiring diagram (right).

Step 3

The canopy installs directly to the electrical box and is meant to fit flush and level to the ceiling finish surface. This pendant requires an electrical box with available holes at 3 1/2" on center spacing. If a box with differently spaced threaded holes is present, additional parts may be required to install the fixture properly, such as a circular universal cross bar.

Install light by screwing the two provided 1" long 8/32 thread machine screws directly into the appropriate holes in the electrical box through the holes provided in the canopy, making sure that canopy sits flat and flush against finish surface.

Step 4

Install medium base light bulb of your choice (60W max) into the socket (SkLO includes an LED bulb with the fixture). Then, carefully insert the socket and bulb inside the glass wrap. Each glass wrap is hand blown and unique, so therefore there is no "right" or "wrong" place for the bulb to rest.

