


PROMETHEUS I 1500

ROUND CANOPY + CABLER GLIDER MOUNTS VERTICAL SUSPENSION




WARNING


ALL ELECTRICAL CONNECTIONS MUST BE MADE BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH THE REGULATIONS AND CODES GOVERNING THE AREA FOR WHICH THE CHRISTOPHER BOOTS FIXTURE IS INTENDED TO BE INSTALLED. FAILURE TO DO SO MAY RESULT IN SERIOUS HARM OR DAMAGE TO PROPERTY AND LIFE, AT THE OWNER'S LIABILITY AND EXPENSE. CHRISTOPHER BOOTS WILL NOT BE HELD LIABLE FOR ANY DAMAGE CAUSED FROM INSTALLATION.

- 1 Wearing gloves, unpack POWER CABLE & SUSPENSION WIRES attached to the fixture.
Next unpack the ROUND CANOPY.
Do not unwrap the PENDANT, in order to prevent any damage that may occur during installation.


2 Ensure PENDANT is the right way up and SUSPENSION WIRES are not tangled.




3 Refer to CANOPY SETOUT below.
Prepare ROUND CANOPY and CABLE GLIDER MOUNTS with their respective INSTALLATION GUIDES.



- 4 Wearing gloves, unpack QUARTZ CRYSTALS straight from the box onto WHITE MAGNETIC SURFACE of PENDANT.
Start packing QUARTZ CRYSTALS onto PENDANT at 5 points, beginning at SUSPENSION WIRES.
This will ensure the weight of QUARTZ CRYSTALS do not overload the fixture at any point.



Ensure MAGNET on QUARTZ CRYSTAL makes full contact with WHITE MAGNETIC SURFACE on PENDANT.
This may mean rotating the QUARTZ CRYSTAL until MAGNET makes full contact.
Place QUARTZ CRYSTALS onto PENDANT tightly, without overlapping.
Cover as much of the visible LED as possible.



- 5 Conduct a final visual assessment of PROMETHEUS I to ensure proper fitting.

Once satisfied everything is in working order, installation is complete.

Please dispose of packaging material thoughtfully.

PROMETHEUS I is a solid fixture requiring very little maintenance over the years. Changes in appearance of hand applied unlacquered finishes will vary as they are designed to age in appearance.

If your PROMETHEUS I is treated with care, it will shine brightly for many years to come.

CARE INSTRUCTIONS

- The PROMETHEUS I pendant is for indoor use only and operable to a maximum ambient temperature of 60° Celsius. The lamping of this luminaire, is a non-user replaceable source and must only be replaced by CHRISTOPHER BOOTS, an appointed agent and/or qualified professional of CHRISTOPHER BOOTS. Should your pendant require relamping, please contact sales@christopherboots.com to make necessary arrangements.
- Remove dust by simply running an electrostatic duster or dry cloth every few weeks over all external surfaces.
- Take particular care when dusting internal surfaces as these are extremely delicate. A clean lint-free cloth will be ample.
- Crystals are attached with rare-earth magnets: they can easily be removed for washing in warm water and detergent whenever you feel the need for more sparkle.
- Under no circumstances should the fixture be cleaned with any type of liquids/detergents or solvents.
- We recommend using micro fibre cloths.
- If more than dusting is required, please contact us at: sales@christopherboots.com

WARRANTY

1. Christopher Boots offers a 36 month / 3 year warranty from date of receipt of balance payment on all light fittings supplied (not installation) against mechanical defects.
2. Christopher Boots will repair or replace defective components or product within this warranty period.
3. Warranty for components includes:
4. LED lamps and strips: 3 years / 36 months after receipt.
5. LED drivers 60w: 3 years / 36 months after receipt.
6. LED drivers 100w + 150w: 5 years / 60 months after receipt.
7. Incandescent lamps: no warranty – no manufacturer warrants filament lamps.
8. Fixtures are clearly labeled with maximum allowable wattage therefore responsibility of installer / end client to ensure correct lamps & wattages are compliant.
9. Use of higher wattage bulbs than indicated will forfeit warranty.
10. Warranty claims require client to cover shipping enroute back for repair.
11. Any questions? Contact sales@christopherboots.com

CHRISTOPHER BOOTS WILL NOT BE HELD RESPONSIBLE FOR THE FOLLOWING

1. Damage caused by improper cleaning solutions or methods.
2. Damage caused by improper installation or assembly by customer or customer's agent.
3. Damage caused by improper use of light bulbs:
4. Installers ensure screwing lamps / glass lamp cover inline with trajectory of product branch + lampholder upon lamp replacement.
5. A screwing motion of slightest angle may cause cross-threading & breakage not covered under warranty.
6. Damage caused by exposure to weather or improper environment – client to check IP rating prior to purchase.
7. Changes in appearance of hand applied finishes or unlacquered finishes.
8. Please note that finishes are designed to age in appearance.
9. Any costs of installation, removal, or re-installation.
10. Restoration, repair work & any parts purchased separately from supplied light fixtures.
11. Damage caused during shipping. All items are packed specifically for global transport.

DAMAGES

1. Damages must be documented and reported within 7 business days of receipt.
2. Photo evidence will be required upon reporting of damage claim.
3. Christopher Boots is not responsible for repair or replacement of damages reported after this time.
4. If damage has occurred in shipping, all packaging must be retained by receiver. Failure to do so may invalidate any claim.

RETURNS

1. Because of the hand-made nature of our product, we unable to offer returns.

WARRANTY AGAINST DEFECTS

A. Definitions

In this warranty **Australian Consumer Law** means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010.

Goods means the product or equipment that was purchased in Australia and listed in the Applicable Product Ranges below.

Manufacturer, We or us means

Christopher Boots Pty Ltd
ABN 20 161 794 574

Supplier means the authorized distributor or the licensed electrical contractor that sold you the **Goods**.

You means you, the original end-user purchaser of the **Goods**.

B. Warranty Period and Details

The products detailed above are covered by a warranty against manufacturing faults and defects, provided that:

The product is properly installed, and installation is consistent with the manufacturer's instructions, and is installed by suitably trained and qualified installer. The product is not subjected to any unauthorised modifications.

The product is only used for the purpose of decorative illumination, in line with its designated purpose.

The product use is in normal conditions.

Any faults or defects attributable to the misuse, abuse, accident or non-observance of the manufacturer's instructions on the part of the user are specifically excluded.

C. Extent of the Warranty

Goods that prove defective within the Warranty Period by reason or improper workmanship or faulty material, we may, at our own discretion, either repair or replace the **Goods** without charge.

This warranty does not cover any cost related to removal, shipping to or from the return point, or reinstallation of the replace or repair item.

Any parts of the **Goods** replaced during repairs or any product replaced remains the property of Christopher Boots Pty Ltd.

In the event of the **Goods** being replaced during the **Warranty Period**, the warranty on the replacement **Goods** will expire on the same date as the **Warranty Period** of the original **Goods** they are replacing.

D. Applicable Date/Commencement of Warranty

This warranty commences from the date of purchase from the point of purchase from us. The details of the point of purchase, as well as all contact information for warranty claims and queries, are detailed below;

CHRISTOPHER BOOTS PTY LTD
328 Napier St. Fitzroy, Vic. Australia 3065
Ph: +61 3 9417 6501
Email: mail@christopherboots.com

E. Claim Process

The customer claim process is as follows:

The customer can make a claim, or enquire about the claim process, by contacting the company as detailed above.

The customer must provide a proof of purchase from the **Supplier**.

Before returning any goods for a warranty claim, the customer must obtain authorization and a Goods Return Authorization (GRA) notice. The customer, at their own expense, then forwards the goods, clearly marked with the GRA notice and with provision for return freight, to us (see above).

Upon receipt of the goods, we will review the claim, and proof of purchase.

If accepted as a valid warranty claim within the terms as described in this document, we will either make suitable repairs or provide an equivalent replacement product.

If the claim is rejected, the customer will be provided with a full explanation, and, if requested, the goods will be returned.

IMPORTANT

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The LED is designed to last for many years, and once it has expired, we offer a replacement service.

Contact us for more information.